

Paral	12	855	7	17	-	855	49.6
	13	306	8	17	128	319	20.3
Diske	14	733	7	17	-	733	42.5
Diske	15						
Diske	16	612	4	17	0	663	20.3
Start	17	977	5	17	300	977	40.5
	18	977	7	17	-	977	56.7
Hard	19	1024	7	17	512	1023	59.4
Hard	20	733	5	17	300	732	30.3
	21	733	7	17	300	732	42.5

<□,□> Move between types <Enter> Select type <Esc> Cancel

<F1> He ntry
<F2> Update <F10> Recall EEPROM defaults <space> Change entry

BIOS/ROM DOS Setup

Time 17:21:44
Date Nov 12, 1990

Boot Source	Disk	Auto-DeskMate	Disable
Speak			e
Mouse	Hard Drive Types		
CPU S	Type	Cylinders	Heads Sectors PreComp Land Size
Boot			
Serial	22	733	5 17 300 733 30.3
Paral	23	306	4 17 0 336 10.1
	24		
Diske	25	615	4 17 0 615 20.4
Diske	26	1024	4 17 - 1023 33.9
Diske	27	1024	5 17 - 1023 42.4
Start	28	981	10 17 - 980 81.3
	29	512	8 17 256 512 33.9
Hard	30		
Hard	31		
	32		

<□,□> Move between types <Enter> Select type <Esc> Cancel

<F1> He ntry
<F2> Update <F10> Recall EEPROM defaults <space> Change entry

BIOS/ROM DOS Setup

Time 17:21:44
Date Nov 12, 1990

Boot Source	Disk	Auto-DeskMate	Disable
Speak			e
Mouse	Hard Drive Types		
CPU S	Type	Cylinders	Heads Sectors PreComp Land Size
Boot			
Serial	33		
Paral	34		
	35	1023	9 17 - 1023 76.3
Diske	36	1024	10 17 1023 1023 84.9
Diske	37	989	5 17 128 989 41.0
Diske	38	1024	5 17 1024 1024 42.4
Start	39	820	6 17 820 820 40.8
	40	1024	8 17 1024 1024 67.9
Hard	41	306	6 17 153 306 15.2
Hard	42		
	43		

BIOS/ROM DOS Setup

Time 17:21:44
Date Nov 12, 1990

Boot Source	Disk	Auto-DeskMate	Disable
Speak			e
Mouse			
CPU S			
Boot			
Serial			
Parallel			
Diske			
Diske			
Diske			
Start			
Hard			
Hard			
Non-Standard	755	16	17
			-
			754
			100.1

<□,□> Move between types <Enter> Select type <Esc> Cancel

<F1> Help <F10> Recall EEPROM defaults <space> Change entry

<F2> Update