



- | | | |
|------------------------------|-----------|----------------------------------|
| Microphone/Line Audio Jumper | - E6-E7 | Microphone (default) |
| | E7-E8 | Line-audio output |
| Video Interrupt Jumper | - E1 - E2 | IRQ 5 set for Video Sync |
| | E2 - E3 | IRQ 5 on expansion bus (default) |
| Printer SLCTIN* Jumper | - E4 - E5 | ON connects SLCTIN* to printer |
| | | OFF ties SLCTIN* high (default) |

These are user selectable jumper locations.