

If you use software that lets you select any of the following printer drivers, you can control most printing functions through the software:

Tandy DMP-136 or DMP-137  
IBM ProPrinter  
Epson FX-850  
Epson EX-800 with color support

DeskMate Drivers: DMP-135, DMP-136, and DMP-137

There is a color driver available from Computer Support Services for DeskMate versions 3.0 and up.

Note: The DMP 135 is not a color printer, however, the driver will work with the printer in Epson mode.

Note: In DeskMate 3.04 and 3.05, the DMP-135 and DMP-136 will be listed in the list of printers. However, in DeskMate versions before 3.04, the printers are not listed as part of the printer choices.

Note: Use the DMP-136 driver option for the DMP-137 printer.

The new drivers are easily installed, simply copy the files from disk to the DeskMate version 3.x hard drive directory, this will overwrite some of the existing printer drivers. (For a floppy version of DeskMate, copy the files to each disk.)

Selecting the Driver:
-----------------------

You can make this driver your default driver by following these instructions:

1. Select Setup from the Accessory Menu (F10)
2. Select the Printer Setting Option (F2)
3. Choose DMP135/136 in the Printers List box (DeskMate 3.04 and 3.05)  
\* or choose IBMGRAPHIC (DeskMate 3.00, 3.02, and 3.03)
4. Choose any other applicable setting.
5. Press OK to save the new choice.

\*Note: If the DeskMate version is prior to version 3.04, choose IBM GRAPHICS as your printer driver. When the new driver is installed, it has the ability to check to see if your printer is set to color or not.

Note: Do not choose OTHER and use the DMPEIBMM.RES as this will give you an error message of INAPPROPRIATE PRINTER FILE.

(dtc-08/06/93)

□