

If your software does not let you specify character format, you can manually select one of the following print modes:

- * LQ (Letter-Quality)--Higher resolution than the other two modes but slower
- * DP (Data-Processing)--Lower resolution but faster than the LQ mode.
- * SSD (Super-Speed-Draft)--Same resolution as DP mode but the print is compressed; faster than the other two modes.

When you turn on the printer it is set to LQ mode. Follow these steps to change the print mode:

1. Press ON/OFF LINE so that the ON/OFF LINE indicator lights.
2. Repeatedly press LF/FF until the ON/OFF LINE indicator shows the desired setting, as follows;

Mode	ON/OFF LINE INDICATOR
LQ	Blinks Once
DP	Blinks Twice
SSD	Blinks Three Times

Note: The SSD print mode is primarily for normal character printing. If you send graphics information or characters with some special attribute (superscript/subscript, for example) in SSD mode, the print result might not be the same as it would be in DP or LQ mode. Also, if you try to print graphics intermixed with text while in SSD mode, some of the text might print over some of the graphics.

Indicator Definitions:

The following chart shows the meaning of the indicators on the printer's front panel:

Indicator	ON	OFF	Flashing
Power	Power is on.	Power is off.	Slowly: The printer is out of paper. Rapidly: An error condition occurred.
ON/OFF LINE	Printer is on line and ready to print.	Printer is off line and not ready to print	The print head is too hot. Printing automatically resumes when the print head cools.

(jej 04/25/94)