



1. POWER ON/OFF SWITCH. Press to turn the VM-2's power ON. Press again to turn the power OFF.
2. POWER ON INDICATOR. This indicator illuminates when the power switch is ON.
3. GREEN PHOSPHOR, HIGH-RESOLUTION VIDEO SCREEN. Front viewing surface.
4. H-HOLD CONTROL. Screwdriver adjust. Stabilizes the picture when the display "scrolls" horizontally.
5. BRIGHTNESS CONTROL. To adjust the picture brightness, use this control.
6. V-HOLD CONTROL. If the display "rolls" vertically, use this control to stabilize the picture.
7. CONTRAST CONTROL. To improve contrast of the characters with the screen, adjust this control.
8. INPUT SIGNAL RCA SOCKET. Plug the RCA pin cable plug into this connector. Connect the other end to the composite video output.
9. POWER CORD
Plug this power cord into an AC, 120 V (240 V for UK & Australian models) electrical outlet.

(css 07/27/93)