

SETTINGS Power Switch ON
 On Line Switch to ONLINE
 Set Dip Switch 1

Dip Switch 1 *=Standard Settings (Parallel)
 OFF=OPEN

1	* OPEN CLOSED	Normal Operation Self Tests as soon as Printer Goes OffLine.
2	* OPEN CLOSED	European Symbols Japanese Symbols
3	* OPEN CLOSED	Carriage Return and Line Feed Carriage Return and NO Line Feed
4	OPEN * CLOSED	Carriage Return disregarded After CR or LF Carriage Return is NOT Disregarded (Switch Only Effective When Switch 3 is OPEN)

* JP1 ASCII/TANDY (Jumper Installed for Tandy Mode)

LINE PRINTER V (TEC)

INTERNAL DIP SWITCH SETTINGS:

SWITCH	SYMBOL	ON	OFF
1	Mode	Test	Normal
2	Char.Set	Kana	ASCII
3	CR/NL	CR	CR+LF
4	NL/LF	CR+LF	LF