Graphics Display Adapter (250-3043) Layout Faxback Doc. # 2074



Note: Refer to Faxback Doc. # 2072 for settings for this board and the Main logic board.