

MAP 1300: Game Control Adapter

Symptom Explanation	Conditions That Could Cause This Symptom
You have entered this MAP because you received a 13XX error message, or suspect a problem with the Game Control Adapter.	<ul style="list-style-type: none">• The Game Control Adapter is failing.• A joystick or paddle is failing.

Note: A joystick or paddle must be installed to run this test.

001

- Power off the system.
- Insert the Advanced Diagnostics diskette into drive A.
- Power on the system.
- Run the Game Control Adapter tests. Use the **(RUN TESTS ONE TIME)** option.
- Follow the instructions on the screen.

DID YOU RECEIVE AN ERROR MESSAGE?

Yes No

|
|
002

Continue with Step 004 in this MAP.

|
003

Replace the Game Control Adapter.

screen changes from **RELEASED** to **PRESSED**.

- After pressing all buttons on the joysticks or paddles, press any key on the keyboard to continue.

DID YOU RECEIVE AN ERROR MESSAGE?

Yes No

|
010

If all buttons showed **PRESSED** when tested, replace the Game Control Adapter. If one or more of the buttons did not show **PRESSED** when tested, replace the joysticks or paddles.

011

You have successfully completed the Advanced Diagnostics tests. If you suspect an intermittent problem, start an error log. If you need instructions, refer to the Reference manual.

Notes:

